

Stock Tractor Pull Rules

\$15.00 Hook Fee per Class

Weight Classes: 6,000; 7,500; 9,500; 11,500; 13,500; 15,500

Contest is open to tractors manufactured after 1960.

Tractors that cannot meet the following rules may pull in the open classes with superintendent or Tech approval may only pay stock \$\$.

Announcements made the day of the pull will take precedence over written rules.

1. All tractors that have a high idle speed equal to or less than published in the A&W Dino Test Book, The Nebraska Tractor Test PTO Data, will pull in this class.
2. Tractor and engine must both be from the same manufacturer.
3. Must have working PTO.
4. Must pull from stock draw bar. Wheelie bars permitted.
5. No cut tires.
6. Tractor must be equipped with stock pumps only.
7. Only manufactures stock side curtains permitted
8. No four wheel drive tractors allowed.
9. Weight includes driver. No weight or driver changes after weigh-in.
10. Draw bar height maximum 18" from ground in 6,000 - 7,500.
11. Draw bar height maximum 20" from ground in 9,500 -11,500 - 13,500 - 15,500 classes.
12. Draw bar may not be less than 18" from center of axle, not more than 1" in thickness and must have a 3" wide 3/4" long opening. Pulling point may not be more than 1 1/2" from back edge of hitching device.
13. No tampering of hydraulic control of draw bar while pulling
14. Rubber tires only, no tire chains, or dual wheels permitted.
15. Committee has the right to accept or reject all entries.
16. Judges have the right to stop contestant's tractor if the tractor is being operated in an unsafe manner.
17. All minors must have written consent of parents or guardian to enter contest.
18. A member of the committee prior to making pull will check draw bar height.
19. Tractors may be rechecked after pull is made if there is any question of rule violation.
20. Contest winners to be decided by total distance pulled.
21. Tractors will be weighed prior to making pull and after pulling on portable scales on the ground.
22. All weight must be securely fastened. Losing any weights while pulling results in disqualification.
23. Operators must remain seated during the pull, and must have complete control of tractor at all times
24. Tractors may pull in two weight classes, but only once in each class.

25. Premiums: 1st- \$75 2nd- \$50 3rd- \$40 4th- \$30